


## Electric Confetti / Streamer Canon



### Instructions for use


#### **Electric Confetti Launcher (EFF200/EFF250)**

- Dimensions: Various sizes from 30cm,40cm,50cm,60cm,70cm,80cm
- Weight: Varies
- Voltage; None (product fired from Electric Confetti Canon)
- Internal Nitrogen Canister for propulsion
- Spray Range: 12metres
- Single Operation
- Available in Confetti and Streamer versions

To obtain the best performance from your confetti Canon please read the instructions before use.

1. Before use please check the device to ensure no damage has occurred during transit, in the event of any damage do not use the product and contact your dealer.
2. This machine is designed to be hand held and is one shot use only.
3. When using the product aim above the heads of people, never point the product at a person.

# EFX (Entertainment FX)



## OPERATION:

1. Refer to the diagram above.
2. The Electric Canons can only be used with the Electric Firing System
3. Break the paper top of the canon (4).
4. Insert the base of the Electric Canon into the Canon Holder (1) of the firing device.
5. Connect the fly lead of the canon to the socket on the firing system .
5. Adjust the angle of the canon in the direction you wish to blow the streamers/confetti ideally above people's heads
6. Fire the canon when ready using the Firing system.
7. This is a one use product, dispose of the empty casing safely.



## **SAFETY INFORMATION SHEET**

**Product Classification:** Professional use Confetti/Streamer shooter

The product is classified as hazardous in accordance with Regulation (EC) No 1272/2008

**Chemical :** Nitrogen compressed Gas H280  
(classification to EU directives 67/548/EEC or 1999/45/EC)

The product labelling is in accordance to regulation (EU) 1272/2008 Hazardous pictograms.  
Hazardous statement: H280– contains gas under pressure; may explode if heated.

The Confetti/Streamers used inside of the product are fireproof in accordance to EN 11925-2-2002

## **Warranty**

This product carries a 1 year warranty from the date of purchase subject to the following conditions:

- This warranty is only valid for products used in accordance with the manufacturer's Instructions.
- This product must not be modified or changed in any way. Any such modifications will invalidate this warranty.
- Proof of purchase will be required in order to validate warranty.
- No responsibility or liability is accepted for any direct or consequential damage, loss or other expense arising from misuse, or incorrect installation or operation of this appliance.

**Distributed in the UK by**



**Tel:** 01458.833186

**E-mail:** [info@batmink.co.uk](mailto:info@batmink.co.uk)

**Web:** [www.batmink.co.uk](http://www.batmink.co.uk)