

## Handheld Confetti Launcher



### Instructions for use

**This product is available in 21" and 42"**

#### **21" Confetti Launcher (EFF500.21)**


- **Dimensions: 72cm x 5cm x 7.5cm (21" version)**
- **Weight: 0.6Kg (excludes CO2 Canister)**
- **Voltage; None**
- **Spray Range: 6-8metres**
- **Simple Operation and repeat Use.**

#### **42" Confetti Launcher (EFF500.42)**

- **Dimensions: 126cm x 5cm x 7.5cm (21" version)**
- **Weight: 0.8Kg (excludes CO2 Canister)**
- **Voltage; None**
- **Spray Range: 10-12metres**
- **Simple Operation and repeat Use.**

**To obtain the best performance from your confetti launcher please read the instructions before use.**

1. Before use please check the machine to ensure no damage has occurred during transit, in the event of any damage do not use the product and contact your dealer.
2. This machine is designed to be used in conjunction with a CO2 Gas Canister (16gram) and either streamers or confetti products which are purchased separately.
3. When using the product aim above the heads of people, never point the product at a person.



1. **Screw thread for connecting CO2 Canister**
2. **Ball Valve and Handle for “On” and “Off” operation**
3. **Gas Storage Unit**
4. **Shoot Tube for confetti and streamers**
5. **CO2 Canister 16gram**

### **OPERATION:**

1. Close the Ball Valve (2) handle
2. Fill the Shoot Tube (4) with Confetti or Streamers
3. Please wear gloves when using the CO2 Canisters.
4. Screw the CO2 Canister (5) clockwise onto the screw thread of the machine (1) until tight.
4. Note: This operation should be carried out as quickly as possible to avoid leakage.
5. The gas from the CO2 canister will fill the Gas Storage unit (3) ready for operation, this will take approximately one minute.
6. To operate point the tube in the direction of fire (ideally at an upward angle) and turn the handle (2) quickly to release the pressurised gas, shooting the streamers into the air.
7. After use unscrew the CO2 Canister. Note; Wear gloves when handling the CO2 canister to avoid a freeze injury.
8. You can now repeat the operation to fire again.

## TROUBLESHOOTING

PROBLEM	REASON	SOLUTION
Streamers or Confetti does not shoot any distance	When connecting the CO2 canister you have not allowed enough time for the gas to fill the Gas storage chamber (3).	After you have screwed on the CO2 canister allow one minute before use.
	Turning on the Ball Valve too slowly	Turn the handle (Ball valve) quickly
CO2 leakage when screwing on the canister	A little leakage is normal	Screw the CO2 Canister onto the device as quickly as possible
CO2 leakage when attached to the device	The Gas storage tank has become defective	Contact the dealer and replace the unit.
When screwing on the CO2 canister the machine starts shooting the confetti	The handle of the Ball Valve is not closed	Close the Ball Valve

## Warranty

This product carries a 1 year warranty from the date of purchase subject to the following conditions:

- This warranty is only valid for products used in accordance with the manufacturer's Instructions.
- This product must not be modified or changed in any way. Any such modifications will invalidate this warranty.
- Proof of purchase will be required in order to validate warranty.
- No responsibility or liability is accepted for any direct or consequential damage, loss or other expense arising from misuse, or incorrect installation or operation of this appliance.

Distributed in the UK by



Tel: 01458.833186

E-mail: [info@batmink.co.uk](mailto:info@batmink.co.uk)

Web: [www.batmink.co.uk](http://www.batmink.co.uk)