

**EFX** (Entertainment FX)

## CONFETTI CANON DMX



### Instructions for use


#### **CONFETTI CANON (EFF525)**

- Dimensions: 54cm x 28cm x 28cm
- Weight: 9Kg
- Voltage; 240volt 50Hz
- Power Consumption: 1200watts
- Spray Range: 8-10 metres
- Confetti Capacity: 0.5 Kilo
- Spray Time: 30-60 seconds
- Control: Remote DMX
- Simple Operation and repeat Use.

To obtain the best performance from your Confetti Canon please read the instructions before use.

1. Before use please check the machine to ensure no damage has occurred during transit, in the event of any damage do not use the product and contact your dealer.
2. This machine is designed to be used in conjunction with either streamers or confetti products which are purchased separately.
3. When using the product aim above the heads of people, never point the product at a person.

# EFX (Entertainment FX)



1. Confetti Sprout
2. Locking Device
3. Air intake
4. Mains Inlet
5. DMX Inlet/outlet 3 Pin XLR
6. Confetti Storage
7. DMX Display and Dipswitches

## OPERATION:

1. Place the Confetti Canon in a suitable place
2. Adjust the angle of the machine using the locking devices (2) you can adjust through 45 degrees.
3. Fill the machine with confetti (6) (maximum load 0.5 Kilos).
4. Connect the mains lead and DMX lead.
5. Set the DMX Channel allocation on the display (7)
6. The unit can be controlled now via an external DMX controller (1 channel)
7. Once empty switch off the machine and reload with confetti.
6. You can now repeat the operation.

## Warranty

This product carries a 1 year warranty from the date of purchase subject to the following conditions:

- This warranty is only valid for products used in accordance with the manufacturer's Instructions.
- This product must not be modified or changed in any way. Any such modifications will invalidate this warranty.
- Proof of purchase will be required in order to validate warranty.
- No responsibility or liability is accepted for any direct or consequential damage, loss or other expense arising from misuse, or incorrect installation or operation of this appliance.

Distributed in the UK by



Tel: 01458.833186

E-mail: [info@batmink.co.uk](mailto:info@batmink.co.uk)

Web: [www.batmink.co.uk](http://www.batmink.co.uk)